




PalletWorks

PalletWorks® (PW) is a software solution that integrates with packaging hardware to intelligently bridge the gap between the manufacturing floor and the ERP system.



PalletWorks Portal & User Interface


The PW web-based portal is the primary means of operation and is designed to be used on an industrial tablet and/or PC. The software automatically collects and records data throughout the labeling process. Data can be edited, ensuring accurate information is sent to ERP systems.

What's happening in PalletWorks (PW)

What's happening on the production line

1

Set active order in PW portal
(PLC integration/manual entry)



2

PW receives signal from PLC
that an item is created




3

PW sends request to
print item label




4

PW waits for a label to be
scanned to identify any errors



5

PW creates a digital
STACK of the pallet




6

PW sends request to
print pallet label




7

PW waits for a label to be
scanned to identify any errors




1

Order is active on
production line



2

Item is created
(i.e. Scale)




3

Printer/applicator
applies item label




4

Industrial scanner
scans item label



5

Pallet is stacked and
shrink-wrapped



6

Printer/applicator
applies pallet label



7

Industrial scanner
scans pallet label

